



Preparation Instructions

Floor surfaces must be thoroughly clean, dry, and prepared properly. Remove all wax, oil, dust, grease, dirt, and all other foreign materials to ensure good adhesion. A test area of GlossTek 100 & GlossTek 400 may be performed on the prepared surface before full application.

For a non-finished floor

1. Dry mop the floor with a dust mop.
2. Wet mop the floor with a damp mop.
3. Be sure to test the floor for a neutral pH if any cleaner was used. Apply a neutralizer if needed. The floor should be between 7-9 pH before application.
4. Must wait for floor to completely dry before applying GlossTek 100 & GlossTek 400.

For a finished

1. Strip product that is on floor. Use Ecolab recommended Air Strip™ to strip floor.
2. Prepare stripping solution according to manufacturer's directions. Carefully read the label
3. Liberally apply with mop the stripping solution and let dwell on floor for 5-10 minutes.
4. Using a rotary machine and a black pad, go over the entire area to be stripped.
5. Using a brown scrub pad makes it easy to do the edges.
6. Now flood the area with a solution of Quik Fill 310 (2 ounces / gallon) or similar neutral cleaner solution and then wet vac.
7. Clean with clean mop the entire area with the cleaner solution.
8. Then rinse and mop 3-5 times with water until floor is pH neutral and all cleaner residue is removed.
9. Must wait for floor to dry before applying GlossTek 100 & GlossTek 400.



For a new floor

1. Strip product that is on floor. Use Ecolab recommended Air Strip™ to strip floor.
2. Prepare stripping solution according to manufacturer's directions.
3. Liberally apply with mop the stripping solution and let dwell on floor for 5-10 minutes.
4. Using a rotary machine and a black pad, go over the entire area to be stripped.
5. Using a brown scrub pad makes it easy to do the edges.
6. Now flood the area with a solution of Quik Fill 310 (2 ounces / gallon) or similar neutral cleaner solution and then wet vac.
7. Clean with clean mop the entire area with the cleaner solution.
8. Then rinse and mop 3-5 times with water until floor is pH neutral and all cleaner residue is removed.
9. Must wait for floor to dry before applying GlossTek 100 & GlossTek 400.

Demo Order - GlossTek 100 - 800 sq ft			
Item #		Size	Demo Quantity
GLOSSTEK FLOOR CARE PRODUCTS AND EQUIPMENT			
FLOOR COATINGS			
63711315	GlossTek 100	1 gallon kit	2
APPLICATION SUPPLIES			
92031000	12 sticks, 24 gloves, 24 booties, 2 can openers, 1 plastic bag	mixing kit	1
92032170	18" by 3/8" Cover	each	2
92032171	18" Frame	each	1
92032148	18" Tub	each	1
94003902	4 - 8 Foot Extension Pole (light weight)	each	1
92032172	Hot Dog Rollers	2 pack	2
92032173	Hot Dog Frame	each	1
92032160	2" Masking Tape - Blue	each	1
CLEANING SUPPLIES			
92032153	Micro Fiber Mop	each	1
92032154	Micro Fiber Handle	each	1
92032155	Micro Fiber Frame	each	1
MISCELLANEOUS SUPPLIES			
92032162	Box of Rags	each	1
92032174	Caution Tape	each	1
92032165	8' by 12' Drop Cloth	each	1
92032182	pH Pencil Test Kit	each	1