

Stripping Procedures for GlossTek Products

1. Have two mops and mop bucket. Dilute acrylic stripper such as Air Strip at the recommended average dilution. In the other mop bucket have plain water.
2. Mop the floor with the plain water
3. With floor machine, use a 120 mesh abrasion screen underneath a black stripping pad to lightly screen the finish.
4. Wet vacuum the solution and allow to dry thoroughly.
5. On dry floor finish, apply undiluted Napier RemovALL 320 Stripper, using the stripping application roller to spread evenly. Apply appropriate pressure to obtain an even coat.
6. Allow stripper to dwell for 30 minutes, reapplying if necessary to prevent drying.
7. After dwell time, spread the diluted acrylic stripper from the mop bucket over the area and use floor machine with aggressive grit brush or black stripping pad to scrub the area thoroughly.
8. If using a grit brush, after scrubbing with aggressive grit brush, while the slurry remains on the floor, rescrub thoroughly using a black stripping pad.
9. Wet vacuum slurry. If any built up finish remains, immediately repeat steps 6 & 7 and then wet vacuum. For more difficult jobs, it may be necessary to reapply stripper.
10. Thoroughly rinse the floor two to three times using clean water or a diluted neutral cleaner solution.
11. Allow to thoroughly dry and check for pH to insure that the floor is ready to refinish.

Supplies Needed for Stripping: (products highlighted are the minimum required)

STRIP / REAPPLICATION SUPPLIES		
63732714	Napier 320 Urethane Stripper	5 gallons
63732537	Napier 320 Urethane Stripper	1 gallon
92032177	Stripping Application Roller – Carpet Roller	each
92032143	20" Black Strip Pad	each
92032175	Edging Pad Holder	each
92032176	Edging Pad	each
92032166	5" Heavy Duty Scraper 48"	each
92032144	20" 60 Mesh Application Screen	each
92032145	20" 80 Mesh Application Screen	each
92032146	20" 100 Mesh Application Screen	each
92032147	20" 120 Mesh Application Screen	each
92032179	20" Maroon Conditioning Pad	each